

# CLEANTYPE® EASY BASIC

KPL-U10060 (WHITE)



## SPECIAL FEATURES

- IP54 rated medical keyboard
- Nano Silver additive with antimicrobial properties
- 15 cm shorten cable with USB waterproof silicone cap
- 4 standard keyboard LEDs (Num, Scroll, Caps lock, CLEAN Mode)
- Can be cleaned with common detergents
- Additional USB extension cable provided
- Clean mode function to lock keyboard for cleaning

## SPECIFICATION

Number of keys: 105 (US-Layout)  
 Keyswitch technology: membrane  
 Switching cycles: approx. 2 mill. (per key)  
 Protection level: IP54  
 Housing material: plastic  
 Housing colour: white

Interfaces: USB  
 Cable length: 15 cm shorten cable with extension cable  
 Operating temperature: 0°C~ +55°C  
 Storage temperature: -15°C~+60°C  
 Dimensions: 460(L) x 137.9(W) x 22.5(T) mm  
 Weight: approx. 430 g  
 Certification: CE, FCC, RoHs  
 Warranty: 1 year

## ORDER INFORMATION

Cat. No.	Product description	Colour	Layout
KPL-U10060	CLEANTYPE® Easy Basic	White	US
KPL-U10060-DE	CLEANTYPE® Easy Basic	White	German
KPL-U10060-AR	CLEANTYPE® Easy Basic	White	Arabic
KPL-U10060-JP	CLEANTYPE® Easy Basic	White	Japanese
KPL-U10060-TH	CLEANTYPE® Easy Basic	White	Thai

Other layouts, configurations and interfaces on request.

## SUPPLEMENT PRODUCTS

Cat. No.	Product description	Colour
MSI-U10030	WATERPROOF MEDICAL TOUCH SCROLL MOUSE	White
MSI-U20030	WATERPROOF MEDICAL TOUCH SCROLL MOUSE	Black

## SHORT OPERATING INSTRUCTIONS



Turn the cleanmode on and off by pressing both keys (duration 5 sec).



LED will be indicated while the cleanmode is on.

---

## CLEANING INSTRUCTION

### 1) USE DISINFECTANT SPRAYS

Thoroughly spray all surface area and between keys. Wipeaway excess moisture prior to use. It is recommend to use the disinfectant sprays in line with the anufacturer's specifications.

### 2) USE DISINFECTANT WIPES

Use a disinfectant wipes in-line with manufacturer's specification to clean keyboard. Exert slight pressure and wipe the keyboard surface with circular movement.

For further details please refer to below link:

<http://www.gett-group.com/content/service-cleaning-instructions>